

# GLOS AIR™ 400# CARTRIDGE

## OXY'PHARM GLOS AIR™ 400# CARTRIDGE

Hydrogen peroxide solution  
for decontamination.



# GLOSAIR™ 400#

## CARTRIDGE

# OXY'PHARM

## GLOSAIR™ 400# CARTRIDGE

### Consistently protects your environment against pathogens.

Ready to use, OXY'PHARM's biocidal disinfectant is packaged in cartridges, ready for insertion in GLOSAIR 400's Automated Area Decontamination systems. The disinfectant is delivered as a mist of hydrogen peroxide and silver cations. Hydrogen peroxide is an oxidizing agent which kills microorganisms via the hydroxyl free radical. Silver cations inactivate microorganisms by inhibition of protein synthesis.

- 5%–6% hydrogen peroxide solution
- Biodegradable and noncorrosive
- Sealed canisters eliminate direct contact with disinfectant

For use with GLOSAIR™ 400 System.



2 liter  
cartridge

### TECHNICAL SPECS

<b>Chemical composition</b>	5%–6% hydrogen peroxide (H <sub>2</sub> O <sub>2</sub> ); 50 ppm silver (Ag); 95% de-ionised water
<b>Packaging</b>	2 liter/cartridge (approximately 5 applications of a 60 m <sup>3</sup> room)
<b>Shelf life</b>	9 months
<b>On-board life</b>	2 months not exceeding shelf life
<b>Storage</b>	Under normal storage conditions: store products vertically at a temperature between 5°C and 25°C

Use biocides safely. Always read the label and product information before use.



**OXY'PHARM®**

917 rue Marcel Paul • 94500 Champigny-sur-Marne • France  
T : +33 1 48 825 829 • F : +33 1 48 824 613  
commercial@oxypharm.net

[www.oxypharm.net](http://www.oxypharm.net)



### FOR MORE INFORMATION

#### Contact for Europe Area

Mrs Sandrine Remesy  
T : +33 1 48 825 839  
Mob : +33 6 62 946 483  
sandrine.remesy@oxypharm.net

#### Contact for Middle East

Dr Emad Elmidany  
T : +20 100 176 1997  
T : +20 111 087 7407  
emad.elmidany@oxypharm.net

#### Contact for Other Areas

Mr Romain Rouleau  
T : +33 1 48 825 842  
Mob : +33 6 62 946 482  
romain.rouleau@oxypharm.net